



## MOVIE-MITE THREADING

1. Insert film as indicated at A. Film Clip A is pushed back to allow perforations to engage with sprocket teeth.
2. Line up any tooth on sprocket with arrow stamped on film clip A by rotating hand setting knob D counter clockwise. Film channel at B is now cleared of shuttle teeth, allowing film to be edged behind pressure plate at B.
3. Rotate hand setting knob again so arrow at A is between any two sprocket teeth. This assures maintaining upper loop.
4. Swing pad arm C to left and complete threading without slack. Raise pad arm C after completing threading, allowing film to resume position indicated.

## REWINDING

1. Leave reels in same position as when in operation.
2. Remove take-up belt from pulley.
3. Pull out rewind belt and place on feed reel pulley for rewinding. (Do not cross belt.)
4. Feed film back under the original feed reel and rewind.